

NAVODILO ZA MONTAŽO – AVTOMATSKI ODZRAČNIK

- Pri montaži ni potrebno spustiti vse vode iz ogrevalnega sistema, ampak samo na radiatorju .
Na radiatorju zapremo pritočni in odtočni ventil.
Ventil montiramo tako, da je avtomatski odzračnik v vertikalni oz. horizontalni legi, navzdol ne sme biti obrnjen.
- Pri prvem izpustu avtomatskega odzračnika odvijemo vijak za 1-2 obrata. Priteče nekaj kaplic vode ter zrak iz radiatorja nato vijak ponovno dobro pritegnemo.
Nadalje bo odzračevalni odzračnik deloval avtomatsko !
- Prvič se lahko na izpustu pri avtomatskem odzračniku pojavi nekaj kapljic vode.
V nadaljnjem obratovanju se to več ne pojavlja.

Maksimalna temperatura: 100°C,

Maksimalni tlak v radiatorju: 8,5 bar,

Minimalni tlak v radiatorju: 0,1 bar.

Montaža različnih dimenzij avtomatskega odzračnika:

Vent

The manual includes the following components:

- Diagrams:**
 - a1:** Safety warning and identification icon.
 - a2:** Installation on a radiator, showing H₂O and Glycol (e.g., Glikol) labels.
 - a3:** Correct and incorrect installation orientations.
 - f1:** Vent operation modes: AUTO (O₂, H₂O), OPEN (O₂ + H₂O, 1-2x), and CLOSE (1-2x).
 - m1:** Prohibited installation on horizontal pipes.
 - m2:** Required 180° rotation for horizontal installation.
 - m3:** Connection sizes: 1/8", 1/4", 3/8", 1/2" with PTFE sealant.
 - m4:** Pressure gauge showing 0.1... 8.5 bar range.
 - m5:** Tightening instructions for the vent cap (1-2 turns).
 - m6:** Air release procedure (1. x ca. 1cl, 2., 3., ... x = 0cl).
- Table:**

DN	G	Typ
6	1/8"	14 (A)
8	1/4"	14 (A)
10	3/8"	17 (A)
15	1/2"	19 (B)
- Technical Specifications:**
 - TB 100°C
 - PB 0.1-8.5 bar
- Product Information:**
 - 298.4001.000
 - EY 98
 - Image of the ER 48 VENT vent cap.